



**ZAPI**<sup>®</sup> S.p.A.

**ELECTRONIC • OLEODYNAMIC • INDUSTRIAL  
EQUIPMENTS CONSTRUCTION**

Via Parma, 59 – 42028 – POVIGLIO (RE) – ITALY  
Tel +39 0522 960050 (r.a.) – Fax +39 0522 960259  
e-mail: [zapi@zapispa.it](mailto:zapi@zapispa.it) – web: [www.zapispa.it](http://www.zapispa.it)

EN

*User Manual*

# ECO SMART DISPLAY



The contents of this publication is a ZAPI S.p.A. property; all related authorizations are covered by Copyright. Any partial or total reproduction is prohibited.

Under no circumstances will Zapi S.p.A. be held responsible to third parties for damage caused by the improper use of the present publication and of the device/devices described in it.

Zapi spa reserves the right to make changes or improvements to its products at any time and without notice.

The present publication reflects the characteristics of the product described at the moment of distribution. The publication therefore does not reflect any changes in the characteristics of the product as a result of updating.



**ZAPI**® is a registered trademark property of Zapi S.p.A.

## NOTES LEGEND



*The symbol aboard is used inside this publication to indicate an annotation or a suggestion you should pay attention.*

---



***The symbol aboard is used inside this publication to indicate an action or a characteristic very important as for security. Pay special attention to the annotations pointed out with this symbol.***

---

# Contents

<b>1</b>	<b>INTRODUCTION .....</b>	<b>5</b>
<b>2</b>	<b>GENERAL CHARACTERISTICS .....</b>	<b>6</b>
2.1	Technical specifications .....	6
2.1.1	Dashboard .....	6
2.1.2	Alphanumeric LCD (Liquid Crystal Display).....	6
2.2	Functional descriptions .....	6
2.2.1	LED function .....	6
2.2.2	Display function.....	7
<b>3</b>	<b>INSTALLATION HINTS.....</b>	<b>9</b>
3.1	Material overview .....	9
3.1.1	Connection cables .....	9
3.1.2	Fuses .....	9
3.2	Installation of the hardware.....	9
3.2.1	Controller heating.....	10
3.2.2	Wirings: CAN connections and possible interferences .....	10
3.2.3	Wirings: I/O connections .....	12
3.2.4	Insulation of truck frame.....	12
3.3	Protection and safety features .....	13
3.3.1	Protection features.....	13
3.3.2	Safety Features.....	13
3.4	EMC.....	13
<b>4</b>	<b>DIAGNOSIS.....</b>	<b>16</b>
<b>5</b>	<b>DESCRIPTION OF CONNECTORS.....</b>	<b>17</b>
5.1	CNA connector: Molex Minifit 6 pins .....	17
<b>6</b>	<b>DRAWINGS.....</b>	<b>18</b>
6.1	Mechanical drawing .....	18
6.2	Connection drawing .....	19
<b>7</b>	<b>PROGRAMMING AND ADJUSTMENTS USING ZAPI HANDSET .....</b>	<b>20</b>
7.1	Adjustment via console.....	20
7.2	Description of console and connection .....	20
7.3	Description of standard console menu .....	21
7.4	Description of programmable functions .....	22
7.5	Special Adjustment menu .....	23
7.6	Parameter change menu .....	23
7.7	Tester menu.....	24
7.8	Description of console using.....	25
7.9	Other functions .....	28
7.10	Description of Alarm menu .....	29
<b>8</b>	<b>STRUCTURE OF DISPLAY MENU.....</b>	<b>30</b>
8.1	Performance rolling.....	32
8.2	Using of Password menu.....	32
8.3	Using dashboard like a console.....	33
<b>9</b>	<b>ANALYSIS OF ECO SMART DISPLAY RELATED ALARMS .....</b>	<b>34</b>
9.1	Eco Smart Display alarms .....	34
9.2	Alarms visualisation .....	34
9.2.1	Traction (node 02).....	37
9.2.2	Traction master (node 03).....	37

9.2.3	Traction slave (node 04).....	37
9.2.4	Pump (node 05).....	38
9.2.5	EPS-AC (node 06).....	38
9.2.6	Valves controller (node 09).....	40
9.2.7	Eco Smart display (nodo 16) .....	41
<b>10</b>	<b>RECOMMENDED SPARE PARTS FOR INVERTER .....</b>	<b>42</b>
<b>11</b>	<b>PERIODIC MAINTENANCE TO BE REPEATED AT TIMES INDICATED.....</b>	<b>43</b>

### APPROVAL SIGNS

COMPANY FUNCTION	INITIALS	SIGN
PROJECT MANAGER	FG	
TECHNICAL ELECTRONIC MANAGER VISA	PP	
SALES MANAGER VISA	MC	

Publication N°: **AEXZP0BB**

Edition: **June 2009**

# 1 INTRODUCTION

Eco Smart Display is an intelligent dashboard connected to the truck system by CAN-BUS line.

This dashboard provides the diagnostic and set-up of the whole truck system:

Eco Smart Display itself, Traction controller, Pump controller, Valves controller.

Eco Smart Display has an alphanumeric liquid crystal display, built-in backlight.

Access to Eco Smart Display menu structure is provided by five operator buttons.

Furthermore Eco Smart Display has five built-in red LED, which provide the operator with a easy information about the status of some truck devices.

# 2 GENERAL CHARACTERISTICS

## 2.1 Technical specifications

### 2.1.1 Dashboard

Voltage:.....	24/36/48/80 V
Can interface [n°]: .....	1
Keyboard buttons [n°]: .....	5
LED [n°]: .....	5
Protection:.....	IP65
External temperature range: standard version .....	0÷50 °C
External temperature range: frozen cell version .....	-35÷50 °C


### 2.1.2 Alphanumeric LCD (Liquid Crystal Display)

Viewing area (WxH).....	50.0x25.0 mm
Number of pixels [n°] .....	128x64
Pixel size.....	0.33x0.33 mm
White LED backlight average luminous intensity.....	250 cd/m <sup>2</sup>

## 2.2 Functional descriptions

### 2.2.1 LED function

The Eco Smart Display has five built-in red LED, which provide the operator with an easy information about the status of some truck devices.



#### **Battery (1)**

This led lights when the measured battery voltage is equal or less than 40% nominal battery voltage.

#### **Wrench (2)**

This led blinks when truck is in alarm condition.

#### **Thermometer (3)**

This led blinks when one truck's controller is in alarm due IMS high temperature.

#### Seat (4)

This led lights when the operator is on the seat.


#### Handbrake (5)

This led lights when the handbrake is activated.



*When the Key Switch is closed, the Eco Smart Display makes a general test lighting and switching off all the LED in sequence.*

### 2.2.2 Display function



#### Battery's state of charge

The battery's state of charge indication (number 1 in figure) is displayed on the left side of the unit; it is shown by ten notches. Each notch represents the 10% of the battery charge. As the battery becomes discharged, the notches turn off progressively, one after the other, in proportion to the value of the residual battery charge. When the residual battery charge is  $\leq 40\%$  the notches displayed start to blink. When BATTERY LOW alarm appears on the traction controller, the battery symbol which is near the notches also blinks.

#### Performance

The number which appears in the rectangle displayed in the top right side of the unit (number 2 in figure) shows the performance mode which is being used in the controller.

Performances can be scrolled pressing button ◀. When one performance is selected, the related information will be sent via can-bus to traction and pump controllers that will manage this data. The standard functioning reduces truck performance passing from performance mode #4 to performance mode #1.

The real meaning, in terms of parameters level of these performances, depends on software present on pump and traction controllers:

- 4 corresponds to highest performance;
- 3 corresponds to medium performance;
- 2 corresponds to low performance;
- 1 corresponds to minimum performance.

**Turtle**

The turtle symbol (number 3 in figure) is normally off; when it appears (fixed) it shows activation of the “soft” mode of the truck, in which maximum speed and acceleration are reduced.

**Hour meter**

The number displayed on the bottom right side of the unit (number 5 in figure) shows the Hours Worked.

The letter present over the hour meter (number 4 in figure) shows which hour meter is displayed:

- K: the key hour meter is displayed;
- S: the seat hour meter is displayed;
- M: the machine hour meter is displayed; it increases if traction or pump control is working.

**Accelerator**

The accelerator level indication (number 6 in figure) is displayed on the central top side of the unit; it is shown by eight notches. When the accelerator level is minimum only a notch is displayed, when the accelerator level is maximum all the eight notches are displayed. Each notch represents 1/8 of the difference between maximum and minimum accelerator level.

**Speed**

The number displayed under the accelerator notches on the center of the unit (number 7 in figure) shows the truck speed. The unit can be km/h or mph depending on the SPEED UNIT parameter setting (see 7.4).

**Wheel position and running direction**

The notch displayed on the left of the hour meter (number 8 in figure) represents the wheel (only one of the nine notches is displayed) and shows the steering angle (it corresponds to the relative truck direction if the truck is running).

The arrow (number 9 in figure) shows the set truck running direction. The arrow point is up when the truck is forward running; the arrow point is down when the truck is reverse running. If the truck doesn't run a dot is displayed instead of the arrow.

## 3 INSTALLATION HINTS

In the description of these installation suggestions you will find some boxes of different colours, they mean:



These are **information** useful for anyone is working on the installation, or a deeper examination of the content

---



These are **Warning boxes**, they describe:

- operations that can lead to a failure of the electronic device or can be dangerous or harmful for the operator;
- items which are important to guarantee system performance and safety

---

### 3.1 Material overview

Before to start it is necessary to have the required material for a correct installation. Otherwise a wrong choice of cables or other parts could lead to failures/ misbehaviour/ bad performances.

#### 3.1.1 Connection cables

For the auxiliary connections, use cables of 0.5-1.0 mm<sup>2</sup> section.

#### 3.1.2 Fuses

- Use a 6.3 A Fuse for protection of the card.
- For Safety reasons, we recommend the use of protected fuses in order to prevent the spread of fused particles should the fuse blow.

---

### 3.2 Installation of the hardware



**Before doing any operation, ensure that the battery is disconnected and when all the installation is completed start the machine with the drive wheels raised from the floor to ensure that any installation error do not compromise safety.**



**Do not connect the module to a battery with a nominal voltage different than the value indicated on the label. A higher battery voltage may cause a logic failure. A lower voltage may prevent the logic operating.**

---

### 3.2.1 Controller heating


Eco Smart Display does not need any means of heat dissipation. The frozen-cell version, provided with a built-in heater, is strongly recommended for frozen-cell applications.

### 3.2.2 Wirings: CAN connections and possible interferences



CAN stands for Controller Area Network. It is a communication protocol for real time control applications. CAN operates at data rate of up to 1 Megabits per second.


It was invented by the German company Bosch to be used in the car industry to permit communication among the various electronic modules of a vehicle, connected as illustrated in this image:



- The best cable for can connections is the twisted pair; if it is necessary to increase the immunity of the system to disturbances, a good choice would be to use a cable with a shield connected to the frame of the truck. Sometimes it is sufficient a simple double wire cable or a duplex cable not shielded.
- In a system like an industrial truck, where power cables carry hundreds of Ampere, there are voltage drops due to the impedance of the cables, and that could cause errors on the data transmitted through the can wires. In the following figures there is an overview of wrong and right layouts of the cables routing.



#### Wrong Layout:




The red lines are can wires.  
 The black boxes are different modules, for example traction controller, pump controller and display connected by canbus.  
 The black lines are the power cables.

This is apparently a good layout, but can bring to errors in the can line.  
 The best solution depends on the type of nodes (modules) connected in the network.  
 If the modules are very different in terms of power, then the preferable connection is the daisy chain.



**Correct Layout:**




**Note: Module 1 power > Module 2 power > Module 3 power**

The chain starts from the –BATT post of the controller that works with the highest current, and the others are connected in a decreasing order of power.  
 Otherwise, if two controllers are similar in power (for example a traction and a pump motor controller) and a third module works with less current, the best way to deal this configuration is to create a common ground point (star configuration).



**Correct Layout:**



**Note: Module 1 power ≈ Module 2 power > Module 3 power**

In this case the power cables starting from the two similar controllers must be as short as possible. Of course also the diameter of the cable concurs in the voltage

drops described before (higher diameter means lower impedance), so in this last example the cable between the minus of the Battery and the common ground point (pointed by the arrow in the image) must be dimensioned taking into account thermal and voltage drop problems.



#### Can advantages

*The complexity of today systems needs more and more data, signal and information must flow from a node to another. CAN is the solution to different problems that arise from this complexity*

- *simplified design (readily available, multi sourced components and tools)*
- *lower costs (less and smaller cables)*
- *improved reliability (fewer connections)*
- *analysis of problems improved (easy connection with a pc to read the data flowing through the cable).*

---

### 3.2.3 Wirings: I/O connections

- After crimping the cable, verify that all strands are entrapped in the wire barrel.
- Verify that all the crimped contacts are completely inserted on the connector cavities.



***A cable connected to the wrong pin can lead to short circuits and failure; so, before turning on the truck for the first time, verify with a multimeter the continuity between the starting point and the end of a signal wire.***

- 
- For information about the mating connector pin assignment see the paragraph “description of the connectors”.

### 3.2.4 Insulation of truck frame



***As stated by EN-1175 “Safety of machinery – Industrial truck”, chapter 5.7, “there shall be no electrical connection to the truck frame”. So the truck frame has to be isolated from any electrical potential of the truck power line.***

---

---

## 3.3 Protection and safety features

### 3.3.1 Protection features

- **Connection Errors:**  
All inputs are protected against connection errors.
- **External agents:**  
The controller is protected against dust and the spray of liquid to a degree of protection meeting IP65.

### 3.3.2 Safety Features



*ZAPI devices are designed according to the prEN954-1 specifications for safety related parts of control system and to UNI EN1175-1 norm.*



*The safety of the machine is strongly related to installation; length, layout and screening of electrical connections have to be carefully designed. ZAPI is always available to cooperate with the customer in order to evaluate installation and connection solutions. Furthermore, ZAPI is available to develop new SW or HW solutions to improve the safety of the machine, according to customer requirements.*  
**Machine manufacturer holds the responsibility for the truck safety features and related approval.**

---

---

## 3.4 EMC



*EMC and ESD performances of an electronic system are strongly influenced by the installation. Special attention must be given to the lengths and the paths of the electric connections and the shields. This situation is beyond ZAPI's control. Zapi can offer assistance and suggestions, based on its years experience, on EMC related items. However, **ZAPI declines any responsibility for non-compliance, malfunctions and failures, if correct testing is not made. The machine manufacturer holds the responsibility to carry out machine validation, based on existing norms (EN12895 for industrial truck; EN50081-2 for other applications).***

---

EMC stands for Electromagnetic Compatibility, and it represents the studies and the tests on the electromagnetic energy generated or received by an electrical device.

So the analysis works in two directions:

- 1) The study of the **emission** problems, the disturbances generated by the device and the possible countermeasure to prevent the propagation of that energy; we talk about “conduction” issues when guiding structures such as wires and cables are involved, “radiated emissions” issues when it is studied the propagation of electromagnetic energy through the open space. In our case the origin of the disturbances can be found inside the controller with the

switching of the mosfets which are working at high frequency and generate RF energy, **but wires and cables have the key role to propagate the disturbs because they works as antennas**, so a good layout of the cables and their shielding can solve the majority of the emission problems.

- 2) The study of the **immunity** can be divided in two main branches: protection from electromagnetic fields and from electrostatic discharge.  
The **electromagnetic immunity** concern the susceptibility of the controller with regard to electromagnetic fields and their influence on the correct work made by the electronic device.  
There are well defined tests which the machine has to be exposed to. These tests are carried out at determined levels of electromagnetic fields, to simulate external undesired disturbances and verify the electronic devices response.
- 3) The second type of immunity, **ESD**, concerns the prevention of the effects of electric current due to excessive electric charge stored in an object. In fact, when a charge is created on a material and it remains there, it becomes an “electrostatic charge”; ESD happens when there is a rapid transfer from a charged object to another. This rapid transfer has, in turn, two important effects:
  - A) this rapid charge transfer can determine, by induction, disturbs on the signal wiring and thus create malfunctions; **this effect is particularly critical in modern machines, with serial communications (canbus) which are spread everywhere on the truck and which carry critical information.**
  - B) in the worst case and when the amount of charge is very high, the discharge process can determine failures in the electronic devices; the type of failure can vary from an intermittently malfunction to a completely failure of the electronic device.

**IMPORTANT NOTE:** it is always much easier and cheaper to avoid ESD from being generated, than to increase the level of immunity of the electronic devices.

There are different solutions for EMC issues, depending on level of emissions/ immunity required, the type of controller, materials and position of the wires and electronic components.

- 1) **EMISSIONS.** Three ways can be followed to reduce the emissions:
  - A) **SOURCE OF EMISSIONS:** finding the main source of disturb and work on it.
  - B) **SHIELDING:** enclosing contactor and controller in a shielded box; using shielded cables;
  - C) **LAYOUT:** a good layout of the cables can minimize the antenna effect; cables running nearby the truck frame or in iron channels connected to truck frames is generally a suggested not expensive solution to reduce the emission level.
- 2) **ELECTROMAGNETIC IMMUNITY.** The considerations made for emissions are valid also for immunity. Additionally, further protection can be achieved with ferrite beads and bypass capacitors.
- 3) **ELECTROSTATIC IMMUNITY.** Three ways can be followed to prevent damages from ESD:

- A) PREVENTION: when handling ESD-sensitive electronic parts, ensure the operator is grounded; test grounding devices on a daily basis for correct functioning; this precaution is particularly important during controller handling in the storing and installation phase.
- B) ISOLATION: use anti-static containers when transferring ESD-sensitive material.
- C) GROUNDING: when a complete isolation cannot be achieved, a good grounding can divert the discharge current through a “safe” path; the frame of a truck can work like a “local earth ground”, absorbing excess charge. **So it is strongly suggested to connect to truck frame all the parts of the truck which can be touched by the operator, who is most of the time the source of ESD.**

## 4 DIAGNOSIS

Main fault diagnostic function concern: parameter and password memory and canbus interface.

# 5 DESCRIPTION OF CONNECTORS


---

## 5.1 CNA connector: Molex Minifit 6 pins


<b>A1</b>	-BATT	Eco Smart Display negative supply.
<b>A2</b>	-BATT	Eco Smart Display negative supply.
<b>A3</b>	CAN-H	Can signal high.
<b>A4</b>	CAN-L	Can low signal.
<b>A5</b>	FREE	Not used.
<b>A6</b>	KEY	Eco Smart Display positive power supply.

# 6 DRAWINGS

## 6.1 Mechanical drawing



## 6.2 Connection drawing




# 7 PROGRAMMING AND ADJUSTMENTS USING ZAPI HANDSET


## 7.1 Adjustment via console

Adjustment of Parameters and changes to the display configuration are made using the Digital Console. Eco Smart Display doesn't have an external connector dedicated to the console: Zapi console must be physically connected to another controller in the CANBUS net, then virtually connected to Eco Smart Display (which is node 16 of the net).

## 7.2 Description of console and connection



## 7.3 Description of standard console menu



---

## 7.4 Description of programmable functions

### MENU SET MODEL

#### 1) **CONNECT TO**

Using CANBUS link, every module connected to can net can act as the “access node” to the canbus net for the external world.

For example the ZAPI hand console (or the PC-Win console) can be physically connected to one module and, by the canbus, virtually connected to any other module of the net.

This parameter is used to select the module to which the user wishes to be connected.

Following the numbers associated to each module in Zapi canbus system are showed.

Number associated in canbus net	MODULE
01	SICOS
02	TRACTION
03	TRACTION MASTER
04	TRACTION SLAVE
05	PUMP
06	EPS-AC
09	MHYRIO/HVC
16	ECO SMART DISPLAY

### MENU SET OPTIONS

#### 1) **OPERATOR PASSW.**

It enables or disables password request at key on.

- ON: Starting password requested
- OFF: Starting password not requested

#### 2) **CONSOLE ENABLE**

It makes available or not console menu.

- ON: Zapi Console menu is available
- OFF: Zapi Console menu is not available

#### 3) **PERFORMANCE TYPE**

It sets the traction mode.

- LEVEL 0: it sets traction mode #1
- LEVEL 1: it sets traction mode #2
- LEVEL 2: it sets traction mode #3
- LEVEL 3: it sets traction mode #4

#### 4) **PERFORM. ENABLE**

It can enable or disable operator changing truck performances using button



- ON: Enabled operator
- OFF: Not enabled operator

#### 5) **SPEED UNIT**

It sets the speed unit.

- OPTION #1: the speed unit is km/h
- OPTION #2: the speed unit is mph

#### 6) **HOURLY COUNTER**

It sets the hour counter displayed.

- OPTION #1: the traction hourcounter is displayed
- OPTION #2: the machine hourcounter managed by the display is displayed

## MENU ADJUSTMENTS

### 1) **SPEED FACTOR**

It adjusts speed coefficient to have the correct truck speed value shown on the display. This coefficient has to be regulated depending on truck mechanic characteristics. It is the result of following formula:

$$\text{Speed Factor} = (88 * rr * p) / \emptyset$$

Where:

rr = total gearbox reduction ratio

p = number of pair pole of the motor

$\emptyset$  = traction wheel diameter expressed in centimeters (cm)

---

## 7.5 Special Adjustment menu

To enter this Zapi hidden menu a special procedure is required. Ask this procedure directly to a Zapi technician.

Following parameter can be configured in this menu:

### 1) **CHECK UP DONE**

It can be ON/OFF. If it is ON it is possible to reset the last maintenance hour-counter, the "SERVICE REQUIRED" alarm and possible reductions.

### 2) **RESET HOURMETER**

It can be ON/OFF. If it is ON it is possible to reset the machine hour-counter (managed by display – HOUR COUNTER set to OPTION #2).

---

## 7.6 Parameter change menu

Following parameters can be configured in this menu:

### 1) **CHECK UP TYPE**

It defines the truck behaviour when a maintenance is required.

- LEVEL 0: the "SERVICE REQUIRED" alarm doesn't appear
- LEVEL 1: the "SERVICE REQUIRED" alarm appears after a time equal to the hours set in the CHECK UP HOURS parameter
- LEVEL 2: the "SERVICE REQUIRED" alarm appears after a time equal to the hours set in the CHECK UP HOURS parameter and after 50 additional hours the truck speed is reduced


### 2) **CHECK UP HOURS**

It defines the hours after which a maintenance is required. It can be adjusted in the 100 to 1000 hours. The resolution is 100 hours (it can be adjusted in steps of 100 hours).

---

## 7.7 Tester menu

Status of keyboard buttons can be monitored in real time in the TESTER menu.




- 1) **KEY 1**  
Status of (▲) keyboard button:
  - ON = Input active, button pushed
  - OFF = Input not active, button released
- 2) **KEY 2**  
Status of (◀) keyboard button:
  - ON = Input active, button pushed
  - OFF = Input not active, button released
- 3) **KEY 3**  
Status of (⊙) keyboard button:
  - ON = Input active, button pushed
  - OFF = Input not active, button released
- 4) **KEY 4**  
Status of (▶) keyboard button:
  - ON = Input active, button pushed
  - OFF = Input not active, button released
- 5) **KEY 5**  
Status of (▼) keyboard button:
  - ON = Input active, button pushed
  - OFF = Input not active, button released

## 7.8 Description of console using


Access to SET MODEL menu.

The only parameter present in SET MODEL function is CONNECTED TO.


By setting this parameter, operator can connect ZAPI Console to every ZAPI product connected to CAN-BUS line. This functionality allows completely control of every ZAPI product without changing the position of the Console connector.




Flow chart showing how to make changes to Option Menu:



Flow chart showing how to make Program changes using Digital Console:



Flow chart showing how to use the TESTER function of the Digital Console:



Remember it is not possible to make any changes using TESTER. All you can do is measure as if you were using a pre-connected multimeter.

## 7.9 Other functions


SAVE function allows to transfer controller parameters to the Pc console memory (using Zapi PcWin console). With this function, a copy of the controller set of parameters can be retained in a Pc and downloaded to another controller (see RESTORE).

RESTORE function allows to download controller parameters from the Pc console memory to the controller Eeprom. Thus, a copy of the parameters stored in a Pc can be downloaded in a controller avoiding the parameter setting operation.

## 7.10 Description of Alarm menu

The microprocessor in the controller records the last five Alarms that have occurred. Items remembered relative to each Alarm are: the code of the alarm, the number of times the particular Alarm occurred and the Hour Meter count. This function permits deeper diagnosis of problems as the recent history can now be accessed.

Flow Chart showing how to use the ALARMS function via the Digital Console:



## 8 STRUCTURE OF DISPLAY MENU

Eco Smart Display present a software structure made by menus and submenus. It is possible to have access to Eco Smart Display menu structure by the 5 operator buttons on the right of the screen.

At turn on the display asks the starting password to have access to the main page (if "OPERATOR PASSW." option is ON), otherwise it shows directly the main page (if "OPERATOR PASSW" option is OFF).

By using user password it's possible to activate the display and have access to the USER MENU (to be customized, and not present in Zapi software version).

By using service password it's possible to activate the display and enter SERVICE MENU which presents two items: "password" and "zapi console".

The main page, if there aren't alarms, shows battery charge, truck speed (in Km/h or mph, it depends on "SPEED UNIT" parameter) and truck/traction hour meter (see "HOUR COUNTER" option); if alarms are present it will show alarm code and node in which alarm has occurred.



From the main page it is possible to have access to the ALARM page (if alarms occur) and to MENUS page.

The "password" submenu allows to manage passwords of Eco Smart Display software structure. It's possible to edit, add and delete passwords.

All passwords are optional (ON/OFF option).

The "zapi console" submenu can be accessible only if CONSOLE ENABLE option is ON. This menu allow user to use dashboard as a real Zapi digital console connected to one module of canbus net.

It follows flow chart diagram of software structure.



---

## 8.1 Performance rolling

From MAIN PAGE using one keyboard button, it is possible to select the performance mode which must be used in traction and pump controllers. Performance can be chosen with button 2, and it is displayed in the top right side of the unit.

When one performance is selected, the related information will be sent via canbus to traction and pump controllers that will manage this data. The standard functioning reduces truck performance passing from high performance mode (4) to economy performance mode (1).

This is possible only if "PERFORM. ENABLE" option is ON.

The real meaning, in terms of parameters level of these performances, depends on software present on pump and traction controllers.

**Button 2** selects in sequence the truck performance (1 → 2 → 3 → 4).

---

## 8.2 Using of Password menu

By entering the service password from MAIN PAGE it's possible to have access to SERVICE MENU. Here with roll buttons (button 1 and 5) it's possible to scroll the submenu items.

With ENTER button (button 3) is possible to enter PASSWORD submenu where the operator can manage Eco Smart Display passwords. In particular it could enable/disable password entering, add, edit and remove passwords.

Inside the PASSWORD menu, use buttons ENTER (3) and OUT (2) to enter or exit submenus and to confirm or cancel operations.

When new password is added, insert:

- the 5 digits password in place of "11111" that appear on the left side of screen;
- the alphanumeric user id in place of "-----";
- the performance type 1/2/3/4 (M) related to the password.
- password type (U): S-service / O-user.

To edit or add passwords use these buttons:

<b>Button 1 / Button 5</b>	change the digit marked by cursor
<b>Button 2</b>	cancel all changing and out from submenu
<b>Button 3</b>	saves all changing
<b>Button 4</b>	shifts cursor on following digit

When there isn't service password in eeprom, it can be used default password "55555" that is deactivated when at least one service password is saved, and it is reactivated when all service passwords are deleted, then it is not possible save the default password.

To delete passwords use these buttons:

<b>Button 1 / Button 5</b>	scroll the passwords saved
<b>Button 2</b>	out from submenu
<b>Button 3</b>	confirm cancellation


### 8.3 Using dashboard like a console

By entering the service password, from MAIN PAGE it's possible to have access to SERVICE MENU. Here with roll buttons (button 1 and 5 ) it's possible to scroll the submenu items.


If option CONSOLE ENABLE is ON, with button 3, it is possible to enter ZAPI CONSOLE submenu, which allows user to use dashboard as a real Zapi digital console connected to one module of canbus net.

Here with roll buttons (button 1 and 5 of keyboard) and enter button (button 3), it is possible to choose which module of canbus net has to be connected to the display.

When the display has been connected, it works exactly like a Zapi digital console (see the example in the following figure)



UP/DOWN: ROLL BETWEEN PARAMETER  
 OUT: DECREASE PARAMETER VALUE  
 SHIFT: INCREASE PARAMETER VALUE  
 \*: EXIT AND/OR SAVE



# 9 ANALYSIS OF ECO SMART DISPLAY RELATED ALARMS

## 9.1 Eco Smart Display alarms

### 1) “EEPROM KO”

Fault in the area of memory where the parameters are stored. This Alarm doesn't inhibit machine operation but operation goes on with default values; if fault is still present when the Key Switch is re-cycled, replace the Eco Smart Display. If the fault disappears, the previously stored Parameters will have been replaced by the default parameters.

### 2) “CAN BUS KO TRAC”

Eco Smart Display doesn't receive messages from canbus line.

Troubleshooting:

- If this fault code is displayed together with other alarm messages, the fault is probably to be looked for in the Eco Smart Display can interface, since the Display seems to be unable to receive any can message. So it is suggested to check Eco Smart Display canbus wiring and connection.
- Otherwise, the fault is in the can interface of other modules present on canbus net.

### 3) “SERVICE REQUIRED”

The maintenance time is elapsed, service intervention required.

## 9.2 Alarms visualisation

When an alarm condition occurs, Eco Smart Display gives the information showing the alarm code and the module in which the alarm occurred.

For example, the information:

A60 ON PUMP

means that the alarm 60 occurred in the pump controller.

Here the table with the alarm codes and the respective meaning is shown.

The meaning of alarms with a code higher than 99 can change depending on the purpose of the application (see following tables).

00	NONE
01	CHOPPER RUNNING
02	NO COMMUNICATION
03	UNKNOWN CHOPPER
04	CONSOLE EEPROM
05	SERIAL ERROR #2

06 SERIAL ERROR #1  
07 CHOPPER NOT CONF  
08 WATCHDOG  
09 FIELD FF FAILURE  
10 EEPROM DATA KO  
11 EEPROM PAR. KO  
12 EEPROM CONF. KO  
13 EEPROM KO  
14 EEPROM OFFLINE  
15 LOGIC FAILURE #5  
16 LOGIC FAILURE #4  
17 LOGIC FAILURE #3  
18 LOGIC FAILURE #2  
19 LOGIC FAILURE #1  
20 FORW VMN LOW  
21 FORW VMN HIGH  
22 BACK VMN LOW  
23 BACK VMN HIGH  
24 LEFT VMN LOW  
25 LEFT VMN HIGH  
26 RIGHT VMN LOW  
27 RIGHT VMN HIGH  
28 PUMP VMN LOW  
29 PUMP VMN HIGH  
30 VMN LOW  
31 VMN HIGH  
32 VMN NOT OK  
33 NO FULL COND.  
34 RGT NO FULL COND  
35 LFT NO FULL COND  
36 PU NO FULL COND  
37 CONTACTOR CLOSED  
38 CONTACTOR OPEN  
39 BRAKE CON CLOSED  
40 BRAKE CONT. OPEN  
41 DIR CONT. CLOSED  
42 DIR CONT. OPEN  
43 RIGHT CON CLOSED  
44 RIGHT CONT. OPEN  
45 LEFT CONT CLOSED  
46 LEFT CONT. OPEN  
47 MAIN CONT CLOSED

48 MAIN CONT. OPEN  
49 I=0 EVER  
50 LEFT I=0 EVER  
51 RIGHT I=0 EVER  
52 PUMP I=0 EVER  
53 STBY I HIGH  
54 LEFT STBY I HIGH  
55 RGT STBY I HIGH  
56 PUMP STBY I HIGH  
57 HIGH FIELD CUR.  
58 NO FIELD CUR.  
59 HIGH BRAKING I  
60 CAPACITOR CHARGE  
61 HIGH TEMPERATURE  
62 TH. PROTECTION  
63 THERMIC LEVEL #2  
64 PUMP TEMPERATURE  
65 MOTOR TEMPERAT.  
66 BATTERY LOW  
67 BATTERY LEVEL #2  
68 BATTERY LEVEL #1  
69 CURRENT SENS. KO  
70 HIGH CURRENT  
71 POWER FAILURE #3  
72 POWER FAILURE #2  
73 POWER FAILURE #1  
74 DRIVER SHORTED  
75 CONTACTOR DRIVER  
76 COIL SHORTED  
77 COIL INTERRUPTED  
78 VACC NOT OK  
79 INCORRECT START  
80 FORW + BACK  
81 BAD STEER 0-SET  
82 ENCODER ERROR  
83 BAD ENCODER SIGN  
84 STEER SENSOR KO  
85 STEER HAZARD  
86 PEDAL WIRE KO  
87 PEDAL FAILURE  
88 TRACTION BRUSHES  
89 PUMP BRUSHES

90	DRIVER 1 KO
91	DRIVER 2 KO
92	DRIVER 1 SIC. KO
93	DRIVER 2 SIC. KO
94	INPUT ERROR #6
95	INPUT ERROR #5
96	INVERTION
97	POSITION HANDLE
98	INPUT ERROR #2
99	INPUT ERROR #1

Here the tables of the alarms with a code higher than 99 for modules which can be connected to the net nodes are shown.

### 9.2.1 Traction (node 02)

242	MOT. TH. SENSOR KO
244	SAFETY KO
245	WRONG SET BAT.
246	SAFETY
247	CAN BUS KO
248	CHECK UP NEEDED
249	THERMIC SENS. KO
250	HANDBRAKE
251	WAITING FOR NODE
253	AUX OUTPUT KO

### 9.2.2 Traction master (node 03)

241	DATA ACQUISITION
242	PUMP WARNING
244	SLAVE WARNING
245	WRONG SET BAT.
246	SLAVE KO
247	NO CAN MSG N. 4
248	CHECK UP NEEDED
249	THERMIC SENS. KO
250	HANDBRAKE
251	WAITING FOR NODE #4
253	AUX OUTPUT KO

### 9.2.3 Traction slave (node 04)

241	DATA ACQUISITION
242	PUMP TEMPERATURE
243	PUMP INCOR. START
244	PUMP VACC NOT OK
245	PUMP TH. SENS. KO

246 MASTER KO  
247 NO CAN MSG N. 3  
249 THERMIC SENS. KO  
250 INPUT MISMATCH  
251 WAITING FOR N. 3

#### **9.2.4 Pump (node 05)**

241 DATA ACQUISITION  
245 WRONG SET BAT.  
246 SAFETY  
249 THERMIC SENS. KO  
250 CAN BUS KO  
251 WAITING FOR NODE  
252 SEAT KO  
253 AUX OUTPUT KO

#### **9.2.5 EPS-AC (node 06)**

##### **EPS-AC**

239 LINE SHORTED  
240 KEY OFF  
241 WAITING DATA  
242 D LINE SENSOR KO  
243 Q LINE SENSOR KO  
244 GAIN EEPROM KO  
245 DATA ACQUISITION  
246 MICRO SLAVE KO  
247 CAN BUS KO  
248 S.P OUT OF RANGE  
249 F.B OUT OF RANGE  
250 MICRO SLAVE  
251 KM OPEN  
252 KS OPEN  
253 KM CLOSED  
254 KS CLOSED

##### **EPS-AC0**

216 MICRO SLAVE #8  
217 MICRO SLAVE #3  
218 CLOCK PAL NOT OK  
219 STEPPER MOT MISM  
220 MOTOR LOCKED  
221 MICRO SLAVE #4  
222 FB POT LOCKED  
223 JERKING FB

225 CURRENT GAIN  
226 NO SYNC  
227 SLAVE COM. ERROR  
228 POSITION ERROR  
237 WAITING DATA  
238 EPS NOT ALIGNED  
239 WAITING FOR TRAC  
240 KEYOFF  
241 ENCODER ERROR  
242 Q LINE SENSOR KO  
243 D LINE SENSOR KO  
244 GAIN EEPROM KO  
245 DATA ACQUISITION  
246 MICRO SLAVE KO  
247 CAN BUS KO  
248 S.P OUT OF RANGE  
249 F.B OUT OF RANGE  
250 MICRO SLAVE  
251 KM OPEN  
252 KS OPEN  
253 KM CLOSED  
254 KS CLOSED

#### **EPS-AC WG**

211 MICRO SLAVE #7  
212 MICRO SLAVE #8  
213 MICRO SLAVE #3  
214 SLAVE ANGLE  
215 SL. LATERAL OUT  
216 SL. ANT. MISSING  
217 ANTENNA FAILURE  
218 AUTO INPUT MISM.  
219 STEPPER MOT MISM  
220 MOTOR LOCKED  
221 MICRO SLAVE #4  
222 FB POT LOCKED  
223 JERKING FB  
225 CURRENT GAIN  
226 SLAVE WATCH DOG  
227 SLAVE COM. ERROR  
228 POSITION ERROR  
229 LOOK. FOR PATH  
230 PATH OUT

231 LATERAL OUT  
232 ANGLE  
233 LOSING PATH  
234 LOSING STRAIGHT  
235 ANTENNA STUFF.  
236 ANT. MISSING  
237 WAITING DATA  
238 EPS NOT ALIGNED  
239 WAITING FOR TRAC  
241 FB SENSOR LOCK.  
242 Q LINE SENSOR KO  
243 D LINE SENSOR KO  
244 GAIN EEPROM KO  
245 DATA ACQUISITION  
246 MICRO SLAVE KO  
247 CAN BUS KO  
248 S.P OUT OF RANGE  
249 F.B OUT OF RANGE  
250 MICRO SLAVE  
252 KS OPEN  
253 KM CLOSED  
254 KS CLOSED

## **9.2.6 Valves controller (node 09)**

### **MHYRIO CB**

228 EVPG1 DRIV SHORT  
229 EVPG2 DRIV SHORT  
230 EVPG3 DRIV SHORT  
231 EVPG4 DRIV SHORT  
232 EVP DRIVER SHORT  
233 EV DRIVER SHORT  
239 WAITING FOR PEV  
241 CAN BUS KO  
242 COIL SHORTED  
243 EV DRIVER KO  
244 EVPG1 DRIVER KO  
245 EVPG2 DRIVER KO  
246 EVPG3 DRIVER KO  
247 EVPG4 DRIVER KO  
248 UNDER VOLTAGE  
249 EVP DRIVER KO  
250 HI SIDEDRIVER KO  
251 WRONG SET BAT.

252 FF VALVES

#### **MHYRIO FLASH**

241 CAN BUS KO

242 SHUNT VALVES

243 DRIVER OPENED

244 DRIVER EVP GR1

245 DRIVER EVP GR2

246 DRIVER EVP GR3

#### **HVC**

241 CAN BUS KO

242 COIL SHORTED

243 EV DRIVER KO

244 KEY-OFF

245 EVP DRIVER KO

246 POSITIVE NOT OK

247 FF VALVES

248 EVP DRIV SHORTED

249 EV DRIV SHORTED

### **9.2.7 Eco Smart display (nodo 16)**

161 CAN BUS KO TRAC

163 SERVICE REQUIRED

# 10 RECOMMENDED SPARE PARTS FOR INVERTER

Part number	Description
C12359	Molex Minitfit Connector 6 pins Female
C12777	Female Molex Minitfit pin harness side

# 11 PERIODIC MAINTENANCE TO BE REPEATED AT TIMES INDICATED

Checks should be carried out by qualified personnel only and any replacement parts used should be original. Beware of NON ORIGINAL PARTS. The installation of this electronic controller should be made according to the diagrams included in this Manual. Any variations or special requirements should be made after consulting a Zapi Agent.

The supplier is not responsible for any problem that arises from wiring methods that differ from information included in this Manual. During periodic checks, if a technician finds any situation that could cause damage or compromise safety, the matter should be brought to the attention of a Zapi Agent immediately. The Agent will then take the decision regarding operational safety of the machine. Remember that Battery Powered Machines feel no pain.

**NEVER USE A VEHICLE WITH A FAULTY ELECTRONIC CONTROLLER**



**IMPORTANT NOTE ABOUT WASTE MANAGEMENT:**

*This controller has both mechanical parts and high-density electronic parts (printed circuit boards and integrated circuits). If not properly handled during waste processing, this material may become a relevant source of pollution. The disposal and recycling of this controller has to follow the local laws for these types of waste materials.*

*Zapi commits itself to update its technology in order to reduce the presence of polluting substances in its product.*

---